

SIDE MOUNT TO FLOOR ADAPTERS
FOR USE WITH R-908X SERIES SIDE MOUNT SEAT BRACKETS IN 996/BOXSTER CHASSIS
INSTALLATION INSTRUCTIONS

Step 1. Remove factory seat from vehicle.

Step 2. Position adapters as shown below.



Step 3. Determine the desired fore/aft seat position by placing seat with R-908X series side mounts onto adapters.

Step 4. Remove seat/side mounts and adapters from vehicle. Attach side mount to the adapters using the supplied hardware. (Use all supplied fasteners - 4 per side.)

Step 5. Reinstall adapter/side mount assembly using original hardware.

Performance driving events are by nature potentially hazardous to your health. Brey-Krause Mfg. Co. Inc. shall not be liable for injury, consequential, or other types of damages resulting from the use or misuse of our products. Proper installation of these parts is critical and should only be done by a professional shop.