

R-9130

C4 SUB STRAP MOUNT BAR
INSTALLATION INSTRUCTIONS

The R-9130 sub strap mount bar was designed to provide a mounting point for an anti submarine strap on C4 model Corvettes with stock seats.

Step 1.

Remove the two front seat track to floor mounting nuts.

Step 2.

Move the seat forward and loosen rear seat track to floor mounting nuts. Move seat rearward.

Step 3.

Tilt seat back until the seat tracks lift above the mounting studs.

Step 4.

Place sub strap bar over studs and lower seat back into place. The guide loop should face forward. It is a good idea to attach the strap to the bar before it is installed.

Note:

The sub strap should be wrapped around the main tube using the guide loop to position the belt.

DO NOT ATTACH THE SUB STRAP TO THE GUIDE LOOP!!!

Step 5.

Reinstall the front seat mounting nuts.

Step 6.

Move seat forward and tighten the rear track mounting nuts.

Performance driving events are by nature potentially hazardous to your health. Brey-Krause Mfg. Co. Inc. shall not be liable for injury, consequential, or other types of damages resulting from the use or misuse of our products. Proper installation of these parts is critical and should only be done by a professional shop.