

**Brey-Krause Model R-9303 – Fire Extinguisher Mount
For Hummer H2, Chevrolet Tahoe / Suburban, GMC Yukon**



This kit mounts a 2.5 lb quick-release fire extinguisher in front of the driver or passenger seat. The bracket bolts directly to the seat and moves with it, allowing it to accommodate drivers of all sizes.

What vehicles does this fit?

- Hummer H2
- Chevrolet Tahoe (2000+)
- Chevrolet Suburban (2000+)
- GMC Yukon, Yukon XL (2000+)

Additional required items not included in kit:

- 2.5 lb quick-release Halon fire extinguisher

Package Contents

- Fire Extinguisher Bracket (1)
- Phillips pan-head screws (4)

Read this before you begin!

Proper installation of this part is critical to their functionality and should only be done by a professional shop.

Brey-Krause Manufacturing co. shall not be held responsible for injury, death, vehicle damage and other types of damage resulting from the use or misuse of our products. This includes improper installation of this product.

INSTALLATION INSTRUCTIONS

Step 1

Attach the fire extinguisher quick-release clamp (included with fire extinguisher) to the mounting bracket as shown. Use the supplied Phillips head screws and mount the clamp as shown.



Step 2

Raise the seat front as much as possible. Remove the two front seat mounting bolts as shown at right.



Step 3

Install the fire extinguisher bracket, mounting it to the studs exposed in step 2. Bolt the nuts back in place to secure the fire extinguisher.



Step 4

Clamp the fire extinguisher in place. If the bottle interferes with the seat, you can loosen the mounting bolts under the seat and adjust the position of the bracket. Installation is now complete.

