



Brey-Krause Mfg. Company
1209 West Lehigh Street
Bethlehem, PA 18018
Phone: 610-867-1401
Fax: 610-866-1433

R-2210: BMW Mini Cooper Fire Extinguisher Mount Instructions

Step One:

Make sure ignition is off and key is removed.

Step Two:

Slide seat all the way back and remove (2) front track mounting bolts.

Step Three:

Unplug all the electrical connectors under the front of the seat.

Step Four:

Slide seat all the way front and remove the (2) rear seat track mounting bolts.

Step Five:

Remove seat from car.

Step Six:

Unbolt the (2) front seat brackets from the track. (2 bolts per side)

Step Seven:

Install fire extinguisher mount between the seat brackets and the track. (Bar side is toward seat.)

Step Eight:

Reinstall (4) front seat mounting bolts.

Step Nine:

Reinstall seat.

Step Ten:

Mount 2.5 lb. fire extinguisher and slide seat all the way back then forward to make sure there is enough clearance with the fire extinguisher mount installed. (Adjust if necessary.)



Figure 1.0 - BMW Mini Cooper



Figure 1.1 - Fire Extinguisher Mount Installed