Sub Strap Mount Installation Instructions for Variable Width Seat Mounts

The seat mounts feature multiple possible mounting locations for the sub strap, to accommodate various seat designs. The sub strap should be between 0° and 20° behind the sub strap opening in the seat floor.

The sub-bar length is adjustable to accommodate various width seats. Both studs should be inserted or unscrewed from the sub mount bar by the same about to ensure the strength and that the harness guide loop stays centered. A half inch open ended wrench should be used on the adjuster to bring flush and hold as the flange head bolts are tightened. Avoid preload on the floor mounts. Tighten Jam Nut.

The R-9258 is designed to use wrap around sub strap mounts. If you have a clip in sub strap, you can convert it to wrap around using an appropriately sized D ring.

Performance driving events are by nature potentially hazardous to your health. Brey-Krause Mfg. Co. Inc. shall not be liable for injury, consequential, or other types of damages resulting from the use or misuse of our products. Proper installation of these parts is critical and should only be done by a professional shop.